


PENETRATIONS MUST BE PROPERLY ANCHORED, GROUTED, AND PREPARED PRIOR TO THE INSTALLATION OF NEW MATERIALS. APPLY ALSAN H-80 PRIMER AS NEEDED.

NOTES:

1. DETAIL TO BE USE IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS, APPLICATION METHODS AND APPROVED DETAILS.
2. ALSAN FLASHING (FLEECE) TO EXTEND MINIMUM 4" ONTO DECK AND 4" VERTICALLY ONTO PENETRATION
3. A SECOND LAYER OF MEMBRANE MAY BE INSTALLED USING THE SAME INSTALLATION METHOD SHOWN ABOVE. 2ND LAYER SIDE LAP TO BE OFFSET 18" FROM THE BOTTOM LAYER.
4. CLEAN ALL PENETRATIONS OF DIRT, RUST AND OIL. ROUGHEN SURFACE OF PIPE BEFORE APPLYING PRIMER. VERIFY PENETRATION IS PROPERLY SECURED TO DECK OR WALL TO AVOID MOVEMENT OF PIPE.

		310 QUADRAL DRIVE	
		WADSWORTH, OHIO 44281	
		(330) 334-0066	
TITLE PIPE PENETRATION FLASHING			
SCALE	DWN	CHK	APPROVAL DATE
NONE	TM	JP	12/11/09
DRAWING NUMBER			REV
BGW-5			0

** USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.