


NOTES:

1. DETAIL TO BE USED IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS, APPLICATION METHODS AND APPROVED DETAILS.
2. SUBSTRATE MUST BE PROPERLY PREPARED AND PRIMED PRIOR TO THE INSTALLATION OF COLPHENE 3000.
3. COLD JOINTS SHOULD BE PROPERLY GROUTED.
4. THIS DETAIL IS A BASIS OF DESIGN, JOB SPECIFIC DETAILS MAY BE REQUIRED PRIOR TO THE START OF CONSTRUCTION.
5. TERMINATION BAR ON COLPHENE BSW (F) INSTALLED AT COMPLETION OF THE VERTICAL WALL POUR.

		310 QUADRAL DRIVE WADSWORTH, OHIO 44281 (330) 334-0066			
		TITLE COLPHENE 3000 TIE-IN TO COLPHENE BSW (F)			
SCALE	NONE	DWN TM	CHK JP	APPROVAL DATE	04/11/11
DRAWING NUMBER	BGW-8			REV	0

** USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.