


- POLYURETHANE CAULKING (BY OTHERS).
- EXISTING COUNTERFLASHING BEND UP AS REQUIRED TO PREPARE SURFACE, CLEAN & APPLY ALSAN LIQUID MEMBRANE. RETURN TO ORIGINAL POSITION AFTER MEMBRANE CURES.
- PREPARE, LEVEL & PATCH SUBSTRATE W/ ACCEPTABLE PATCHING MORTAR PRIOR TO APPLICATION OF ALSAN PRIMER AND LIQUID MEMBRANE (TYP.)
- ALSAN FULLY REINFORCED LIQUID MEMBRANE (FLASHING GRADE) EXTEND 4" (10cm) MIN. HORIZONTALLY ONTO PREPARED AND PRIMED SUBSTRATE.
- ASSURE FULL SATURATION OF FLEECE & CONTACT W/ SUBSTRATE.
- 4" WIDE STRIP ALSAN FULLY REINFORCED LIQUID MEMBRANE (FLASHING GRADE) APPLIED OVER ALL JOINTS, ANGLE CHANGES AND VOIDS. FILL JOINTS & VOIDS W/ ACCEPTABLE PATCHING MORTAR OR PASTE PRIOR TO APPLICATION OF ALSAN LIQUID MEMBRANE STRIPS.
- ALSAN FULLY REINFORCED LIQUID MEMBRANE (SEE NOTE #2).
- MIN. 1/4" SOPRABOARD OR APPROVED MIN. 1/2" RECOVERY BOARD (BY OTHERS) SECURELY ATTACHED TO SUBSTRATE.
- MIN. 1" RIGID BOARD INSULATION SECURELY FASTENED TO SUBSTRATE.

NOTES:
 1. DETAIL TO BE USED IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS, APPLICATION METHODS AND APPROVED DETAILS.

		310 QUADRAL DRIVE WADSWORTH, OHIO 44281 (330) 334-0066						
		TITLE SINGLE BASE PLY FLASHING W/CF LOW FLASHINGS (INSULATED)						
SCALE	NONE	DWN	PBF	CHK	BS	APPROVAL DATE	4/29/09	
DRAWING NUMBER	BI-7						REV	0

** USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.