


NOTES:

1. DETAIL TO BE USED IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS, APPLICATION METHODS AND APPROVED DETAILS.
2. BURN FLEECE WITH HOT AIR WELDER ON EXISTING COLPHENE BSW WATERPROOFING ASSEMBLY PRIOR TO APPLYING COLPHENE LIQUID MEMBRANE AND REPAIR TARGET PATCH.

		310 QUADRAL DRIVE	
		WADSWORTH, OHIO 44281 (330) 334-0066	
TITLE COLPHENE BSW REPAIR PATCH			
SCALE	DWN	CHK	APPROVAL DATE
NONE	TM	GP	07/15/10
DRAWING NUMBER BSW09			REV 0

** USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.