


NOTES:

1. SUBSTRATE MUST BE PRIMED PRIOR TO THE INSTALLATION OF NEW MATERIALS.
2. COMPLETELY ENCAPSULATE REINFORCEMENT WITH A TOP COATING OF COLPHENE H IMMEDIATELY AFTER INSTALLATION. DO NOT LEAVE EXPOSED OVERNIGHT.
3. DETAIL TO BE USED IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS AND APPROVED DETAILS.

		310 QUADRAL DRIVE	
		WADSWORTH, OHIO 44281	
		(330) 334-0066	
TITLE COLPHENE H ISOMETRIC THRESHOLD DETAIL			
SCALE	NONE	DWN TM	CHK JP
DRAWING NUMBER		APPROVAL DATE	
HRW-606		06/14/10	
			REV 0

\*\* USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.