

ALSAN Flashing Kit

- Applied Over Existing Roof Structure
- No Tear Down
- No Disposal Costs
- No Work Interruptions
- No Flames
- No Fumes



Roofing & Waterproofing Contractors

For busy contractors that need to get more repairs done in less time, Soprema offers an ideal solution: Alsan Flashing Repair Kits. In today's hectic business climate, you cannot afford to make repeated trips from the job site to your vehicle, or worse still, from the site back to the warehouse for more supplies. Time is money!

Alsan Flashing Repair Kits provide you with everything you need to make fast, permanent repairs. You will not only save time and frustration, but stocking your vehicles with a kit will put you on repair calls faster than your competition. Being "Johnny-on-the-spot" as soon as your customers call is the surest way for earning repeat business and referrals.

For your discriminating customers who demand the best in maintenance, show them you know your stuff by showing up with the white bucket of distinction... Alsan Flashing.



Building Owners

For discriminating building owners that want to minimize water damage from leaking roofs, Soprema now offers you a smart "insurance policy." Keeping an Alsan Flashing Repair Kit on-hand at each of your buildings can drastically reduce the amount of time it takes to repair any minor leak before it turns into major damage.

The Repair Kits contain everything your maintenance people will need to quickly and efficiently repair leaks caused by negligence, wear or puncture. Water is your worst enemy, and don't be caught short-handed... investing in one Alsan Flashing Repair Kit for each building may be the smartest move you make today.



CORPORATE OFFICE

ALSAN FLASHING KIT

ALSAN Flashing Kit Includes:

- (2) Alsan Flashing 1 Gal.
- (1) Pair of Scissors
- (1) 4" Roller Frame
- (2) 4" Roller Cover
- (2) 4" Brushes
- (2) Mixing Sticks
- (2) Plastic Garbage Bags
- (10) Disposable Vinyl Gloves
- (1) 4" Plastic Putty Knife
- (1) 6" Plastic Putty Knife
- (1) 5-in-One Tool
- (1) Roll of 4" Fleece
- (1) Roll of Duct Tape
- (1) Cural™ Aluminum Sample
- (1) Instructional DVD



Installation Instructions



1 Prepare patch area by removing all loose material to produce a clean, dry surface.



2 Apply ALSAN Flashing liberally with a brush or putty knife.



3 Measure and cut strips of reinforcing material and place on top of first coat of ALSAN.



4 Cover reinforcing material with a second coat of ALSAN Flashing.



5 ALSAN Flashing will dry to a dark brown appearance. If desired, a matching granule can be placed on top of the second coat while the material is still wet, or...



6 ... once dry, Cural™ Aluminizer can be applied to the surface to add an additional layer of protection against solar degradation.