


- NOTES:
1. DETAIL TO BE USE IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS, APPLICATION METHODS AND APPROVED DETAILS.
 2. CRICKETS SHOULD BE LOCATED IN VALLEYS BETWEEN ROOF DRAINS AND SADDLES ON THE HIGH SIDE OF CURBS.
 3. LOCATE ROOF DRAINS AT POINTS OF MAXIMUM DECK DEFLECTION / LOW AREAS FOR DRAINAGE.
 4. SEE APPLICABLE DRAIN, CURB AND MEMBRANE LAYOUT APPROVED DETAILS FOR APPLICATION DIRECTIONS.

		310 QUADRAL DRIVE	
		WADSWORTH, OHIO 44281	
		(330) 334-0066	
TITLE			
Roof Components Used For Positive Slope Drainage			
SCALE	DWN	CHK	APPROVAL DATE
NONE	DMT	PR	9/1/05
DRAWING NUMBER			REV
MISC-002			0

** USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.