


NOTES:

1. DETAIL TO BE USED IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS AND APPROVED DETAILS.
2. WOOD BLOCKING AT OPENINGS IS RECOMMENDED WHEN USING SPRAYED POLYURETHANE INSULATION
3. AIR/VAPOR RETARDER TYPE AND PLACEMENT REQUIREMENTS ARE TO BE DETERMINED BY THE SPECIFIER

		310 QUADRAL DRIVE WADSWORTH, OHIO 44281 (330) 334-0066	
TITLE WINDOW			
SCALE	DWN	CHK	APPROVAL DATE
N.T.S.	RS	JP	11/05/10
DRAWING NUMBER PAR09			REV 0
** USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.			