


NOTES:

1. USE IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS AND APPROVED DETAILS WHILE CONSTRUCTING OTHER ROOF COMPONENTS TO EXCEED CURRENT EDITION REQUIREMENTS OF FM APPROVALS, SMACNA, NRCA, ANSI/SPRI ES-1 AND FLORIDA BUILDING CODE-RAS NO. 111 WITH THE MOST STRINGENT REQUIREMENTS OR RECOMMENDATIONS PREVAILING.
2. SOPREMA ADHESIVES, CEMENTS, MASTICS, PRIMERS AND SEALANTS ARE REQUIRED WHERE INDICATED.
3. THE PIPE DIMENSION DICTATES THE NUMBER OF FASTENERS EQUALLY SPACED AROUND THE PENETRATION, I.E. 4" DIA. => 4 FASTENERS, 8" DIA. =>8 FASTENERS.
4. LEAD FLASHING FLANGE AND POLYESTER REINFORCING MEMBRANE PLY MUST BE PLACED DIAGONAL TO BASE PLY FIELD SEAMS.

		310 QUADRAL DRIVE	
		WADSWORTH, OHIO 44281	
		(330) 334-0066	
TITLE Soprafix Membrane Fastening @ Penetrations			
SCALE	DWN	CHK	APPROVAL DATE
NONE	DMT	PR	10/15/04
DRAWING NUMBER			REV
SFPN-001			0

** USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.