


1. INSTALL THE SOPRASTAR MEMBRANE AS SPECIFIED
2. MEASURE THE TARGET AREA WHERE THE FLASHING PLY WILL BE INSTALLED. CHALK OR MARK WHERE THE FILM WILL BE REMOVED.
3. SCORE THE FILM SURFACE OF THE SOPRASTAR MEMBRANE. TAKE EXTRA CARE TO NOT CUT INTO THE REINFORCEMENT OF THE SOPRASTAR MEMBRANE.
4. HEAT THE SURFACE OF THE FILM WITH A TORCH OR HOT AIR WELDER. BE CAUTIOUS WITH APPLYING EXCESSIVE HEAT AND AVOID DISCOLORING OR BURNING THE FILM THAT IS NOT BEING REMOVED. REFER TO DETAIL SPSTR-001 FOR FURTHER INSTRUCTIONS.
5. SLOWLY PEEL BACK THE FILM LAYER OF THE SOPRASTAR.
6. ONCE THE FILM HAS BEEN REMOVED, THE OVERLAPPING MEMBRANE MAY BE APPLIED.

NOTES:

1. DETAIL TO BE USE IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS, APPLICATION METHODS AND APPROVED DETAILS.
2. SOPREMA ADHESIVES, CEMENTS, MASTICS, PRIMERS AND SEALANTS ARE REQUIRED WHERE INDICATED.
3. WHEN A PROJECT SPECIFICATION REQUIRES SOPREMA TO WARRANT SHOP FORMED METAL(S), ROOFING CONTRACTOR MUST SUBMIT METAL SPECIFICATION AND ALL PROPOSED METAL DETAILS TO THE SOPREMA CORPORATE TECHNICAL DEPARTMENT FOR REVIEW/APPROVAL PRIOR TO BIDDING AND/OR INSTALLATION.

		310 QUADRAL DRIVE WADSWORTH, OHIO 44281 (330) 334-0066		
		TITLE SOPRASTAR BASE FLASHING		
SCALE	NONE	DWN KD	CHK	APPROVAL DATE 05.29.09
DRAWING NUMBER SPSTR-003				REV 1