


1. INSTALL THE FOIL SURFACED MEMBRANE AS SPECIFIED
2. MEASURE THE TARGET AREA WHERE THE FLASHING PLY WILL BE INSTALLED. CHALK OR MARK WHERE THE FILM WILL BE REMOVED.
3. SCORE THE FILM SURFACE OF THE FOIL SURFACED MEMBRANE. TAKE EXTRA CARE TO NOT CUT INTO THE REINFORCEMENT OF THE MEMBRANE.
4. HEAT THE SURFACE OF THE FILM WITH A TORCH OR HOT AIR WELDER. BE CAUTIOUS WITH APPLYING EXCESSIVE HEAT AND AVOID DISCOLORING OR BURNING THE FILM THAT IS NOT BEING REMOVED. REFER TO DETAIL TVALU-001 FOR FURTHER INSTRUCTIONS.
5. SLOWLY PEEL BACK THE FOIL LAYER OF THE MEMBRANE.
6. ONCE THE FOIL HAS BEEN REMOVED, THE OVERLAPPING MEMBRANE MAY BE APPLIED.

NOTES:

1. DETAIL TO BE USE IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS, APPLICATION METHODS AND APPROVED DETAILS.
2. SOPREMA ADHESIVES, CEMENTS, MASTICS, PRIMERS AND SEALANTS ARE REQUIRED WHERE INDICATED.
3. WHEN A PROJECT SPECIFICATION REQUIRES SOPREMA TO WARRANT SHOP FORMED METAL(S), ROOFING CONTRACTOR MUST SUBMIT METAL SPECIFICATION AND ALL PROPOSED METAL DETAILS TO THE SOPREMA CORPORATE TECHNICAL DEPARTMENT FOR REVIEW/APPROVAL PRIOR TO BIDDING AND/OR INSTALLATION.

| | | | |
|--|-----|---|---------------|
|  | | 310 QUADRAL DRIVE | |
| | | WADSWORTH, OHIO 44281 (330) 334-0066 | |
| TITLE FOIL SURFACED MEMBRANE BASE FLASHING | | | |
| SCALE | DWN | CHK | APPROVAL DATE |
| NONE | KD | BS | 09.18.09 |
| DRAWING NUMBER TVALU-003 | | | REV 1 |

** USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.