


NOTES:

1. DETAIL TO BE USE IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS, APPLICATION METHODS AND APPROVED DETAILS.
2. REFER TO PRODUCT DATA SHEETS ON WEB SITE FOR FURTHER INFORMATION. www.soprema.us
3. PRIME MASONRY CHIMNEY WITH APPROVED PRIMER AS NECESSARY
4. INSTALL SOPREMA ROOF UNDERLAYMENT IN ORDER AS SHOWN BY NUMBERS
5. EXTEND SOPREMA ROOF UNDERLAYMENT FROM EAVE TO BELOW CHIMNEY AND FROM ABOVE CHIMNEY TO RIDGE
6. INSTALL SOPREMA ROOF UNDERLAYMENT TO FORM WATER-SHEDDING LAPS
7. REFER TO NRCA OR SMACNA FOR METAL COUNTERFLASHING AND ROOFING OPTIONS AT CHIMNEY

| | | | |
|--|-----|---|---------------|
|  | | 310 QUADRAL DRIVE | |
| | | WADSWORTH, OHIO 44281 (330) 334-0066 | |
| TITLE CHIMNEY | | | |
| SCALE | DWN | CHK | APPROVAL DATE |
| NONE | DMT | ES | 9/23/09 |
| DRAWING NUMBER | | | REV |
| | | | 0 |

** USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.