


NOTES:

1. DETAIL TO BE USE IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS, APPLICATION METHODS AND APPROVED DETAILS.
2. SOPREMA WARRANTS ADHESION TO EXISTING SOPREMA FIELD CAP MEMBRANE PLY WHEN SOPRAWALK IS FULLY HEAT WELDED OR ADHERED WITH 2-PART MEMBRANE ADHESIVE (REMOVE PLASTIC FILM IF PRESENT) EMBED GRANULES MIN. 6" (152mm) AROUND EXISTING CAP SHEET EDGES AND PRIME INNER AREAS BEFORE HEAT WELDING SOPRAWALK.
3. SOPREMA 2-PART ADHESIVE PRIMER (DEPENDING ON APPLICATION METHOD) REQUIRED WHERE INDICATED. SOPREMA SEALANT OR OWNER SPECIFIED SEALANT IS REQUIRED WHERE SEALANT IS INDICATED
4. SOPREMA DOES NOT WARRANT ADHESION TO EXISTING SOPREMA FIELD CAP MEMBRANE PLY WHEN OTHER ADHESIVE METHODS ARE USED.
5. ON SOPRALAST FOIL-CLAD MEMBRANES SCORE, WARM AND REMOVE FOIL-CLADDING IN DESIGNATED WALKWAY AREAS PRIOR TO HEAT WELDING TO ADHERE SOPRAWALK OR APPLYING APPROVED ADHESIVE. ON SPOT ADHERING SOPRAWALK PROTECTION LAYER SECTIONS RE-HEAT BITUMEN AND APPLY GRANULES IN 2" SPACE AREAS.

		310 QUADRAL DRIVE	
		WADSWORTH, OHIO 44281 (330) 334-0066	
TITLE SOPRAWALK OVER FOIL-CLAD MEMBRANE			
SCALE NONE	DWN DMT	CHK PR	APPROVAL DATE 9/1/05
DRAWING NUMBER MISC-007			REV 0

** USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.