



THERMAL INSULATION, COVERBOARD AND ROOFING PLYS APPLIED TO DECK AS SPECIFIED OR REQUIRED

REINFORCING MEMBRANE PLY EXTEND 3" (762mm) BEYOND LEAD

30" (762mm) SQUARE MINIMUM, 2 1/2 LB. TO 4 LB. (1.2kg TO 1.8kg) LEAD OR 16 OZ. (0.5kg) COPPER FLASHING SET IN BED OF SOPREMA MASTIC, PRIME TOP SURFACE BEFORE INSTALLING REINFORCING PLY

DRAIN STRAINER

CLAMPING RING

DRAIN BOWL

DRAIN FLASHING, FIELD BASE, REINFORCING AND MEMBRANE PLYS EXTEND UNDER CLAMPING RING AND TURN LEAD DOWN INTO BOWL 1" (25mm) MIN.

INSTALL A MINIMUM 8" (203mm) WIDE BED OF SOPREMA MASTIC ONTO THE DRAIN FLANGE AND OUT ONTO THE INSULATION PRIOR TO EMBEDDING THE FIELD BASE MEMBRANE PLY INTO THE MASTIC. AFTERWARD, APPLY ANOTHER BED OF MASTIC ON TOP OF THE BASE PLY PRIOR TO THE APPLICATION OF THE PRIMED DRAIN LEAD FLASHING.

WHEN POSSIBLE INSTALL MINIMUM 4' (102mm) DRAIN SUMP IN ANY ONE DIRECTION—OR THAT ADDITIONAL TAPER TO PROVIDE POSITIVE DRAINAGE.

NOTES:

1. DETAIL TO BE USE IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS, APPLICATION METHODS AND APPROVED DETAILS.
2. SOPREMA ADHESIVES, CEMENTS, MASTICS, PRIMERS AND SEALANTS ARE REQUIRED WHERE INDICATED.

| | | | |
|---------------------------------|------------|--|-------------------------|
| | | 310 QUADRAL DRIVE WADSWORTH, OHIO 44281 (330) 334-0066 | |
| TITLE DRAIN W/ CLAMPING RING | | | |
| SCALE NONE | DWN DMT | CHK PR | APPROVAL DATE 9/1/05 |
| DRAWING NUMBER ADR-001 | | | REV 0 |

** USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.