

ELASTOPHENE SANDED, ELASTOPHENE 180
 SANDED OR OTHER SOPREMA APPROVED
 PROTECTION COURSE
 OPTIONS FOR APPROVED ALTERNATE:
 PROTECTION BOARD, SOPREMA APPROVED
 INSULATION, SOPRADRAIN ECO-VENT, ECO 2,
 OR ALTERNATE PER SPECIFIER


FULL SOLID FILL OF SOPREMA APPROVED GROUT,
 EPOXY, OR OTHER APPROPRIATE FILL MATERIAL

6" MIN.
 (15cm)

PIPE PENETRATION IMOBILIZED
 AND ANCHORED FIRMLY TO THE
 VERTICAL WALL

COLPHENE H (180 mils)
 TYPICAL REINFORCED SYSTEM


APPLY SOPRA-FLASH UN TIGHTLY
 OVER PIPE PENETRATION AND ONTO
 BASE COAT OF COLPHENE H
 REFERENCE DETAIL HRW-301



COLPHENE H
 (NO VOIDS)

NOTES:

1. DETAIL TO BE USED IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS AND APPROVED DETAILS.
2. CLEAN ALL PENETRATIONS OF DIRT, RUST AND OIL. ROUGHEN SURFACE OF PIPE BEFORE APPLYING PRIMER. VERIFY PENETRATION IS PROPERLY SECURED TO DECK OR WALL TO AVOID MOVEMENT OF PIPE.
3. REFERENCE DETAIL HR-301 FOR SPECIFIC INSTALLATION GUIDELINES OF PIPE FLASHING MEMBRANE.
4. THIS DETAIL IS APPLICABLE FOR VERTICAL WALL PENETRATIONS (TYPICAL)
5. DRAINBOARD AND/OR INSULATION NOT SHOWN IF REQUIRED

		310 QUADRAL DRIVE WADSWORTH, OHIO 44281 (330) 334-0066	
TITLE VERTICAL PIPE PENETRATIONS			
SCALE	DWN TM	CHK JP	APPROVAL DATE 06/17/10
DRAWING NUMBER HRW-300c			REV 0

** USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.