


NOTES:

1. FOR CONCRETE MASONARY UNIT WALLS (BLOCK WALLS) SEE SOPREMA FOR SPECIAL DETAILING/OPTIONS. ALL CMU WALLS MUST BE 215 MILS REINFORCED SYSTEM
2. ALL SOPREMA VERTICAL WALL MEMBRANE SYSTEMS MUST BE MECHANICALLY FASTENED AT TERMINATION POINT. SOPREMA RECOMMENDS STANDARD REINFORCED JOINT TREATMENT; AT GRADE, TRANSITION TO VERTICAL WALL, WATER/WEATHER PROOFING. SOPREMA RECOMMENDS VERTICAL WALL WATERPROOFING EXTEND ABOVE GRADE AND BEHIND EXPOSED WALL FINISH.
3. SEE SOPREMA FOR OPTIONS ON ELASTOPHENE SANDED REQUIREMENTS FOR BELOW GRADE COLPHENE H 180 MILS ASSEMBLY.
4. CONCRETE SUBSTRATE MUST BE PRIMED/ PREPARED PRIOR TO THE INSTALLATION OF NEW MATERIALS.
5. ELASTOPHENE 180 SANDED IF USED DOES NOT REQUIRE AN ADDITIONAL PROTECTION COURSE CALL SOPREMA FOR DETAILS

		310 QUADRAL DRIVE	
		WADSWORTH, OHIO 44281 (330) 334-0066	
TITLE			
VERTICAL WALL TYPICAL FLASHING TERM.			
SCALE	DWN	CHK	APPROVAL DATE
NONE	TM	JP	12/22/09
DRAWING NUMBER			REV
HRW-406B			0

** USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.