



STEP #1




STEP #2




EMBED GRANULES 12" (305mm) IN ALL DIRECTIONS AROUND AN SBS CAP SHEET SPLIT. PREPARE AND PRIME A 12" (305mm) AREA IN ALL DIRECTIONS ON GRANULATED AREAS OF AN OXIDIZED ASPHALT CAP SHEET SPLIT.

STEP #3



CENTER ON SPLIT AND HEAT WELD ONE LAYER OF 8" (203mm) WIDE SOPRALENE FLAM 180 TO PROPERLY PREPARED SUBSTRATE EXTEND PAST SPLIT 6" MIN. (152mm)


STEP #4



HEAT WELD 1 LAYER OF 12" (305mm) WIDE SOPRALENE FLAM 180 GR TO THE SOPRALENE FLAM 180 BASE MEMBRANE PLY AND EXISTING CAP SHEET. BUTTER & SEAL EDGE AND DRESS UP WITH GRANULES.

NOTES:

1. DETAIL TO BE USE IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS, APPLICATION METHODS AND APPROVED DETAILS.
2. SOPREMA FLASHING ADHESIVE, MASTIC, PRIMER (DEPENDING ON APPLICATION METHOD) REQUIRED WHERE INDICATED.

		310 QUADRAL DRIVE	
		WADSWORTH, OHIO 44281	
		(330) 334-0066	
TITLE GLASS CAP SHEET SPLIT REPAIR – HEAT WELDED			
SCALE	DWN	CHK	APPROVAL DATE
NONE	DMT	PR	9/1/05
DRAWING NUMBER			REV
MISC-011			0

\*\* USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.