





STEP 1:
CUT & APPLY FINGER FLASHING AROUND SUPPORT



----- FOLD LINES
 _____ CUT LINES

STEP 2:
CUT & APPLY STRETCH COLLAR AROUND SUPPORT
OVERLAPPING TABS



OVERLAP TARGET MEMBRANES 2" MIN. AND
ROUND ALL CORNERS

NOTES:

1. DETAIL TO BE USED IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS, APPLICATION METHODS AND APPROVED DETAILS.
2. A FULLY REINFORCED LIQUID MEMBRANE SYSTEM IS DEFINED AS AN ASSEMBLY CONSISTING OF TWO LIQUID RESIN APPLICATIONS & FABRIC REINFORCEMENT INSTALLED BETWEEN THE RESIN LAYERS. REFER TO DETAIL A-1 FOR ADDITIONAL INFORMATION.

		310 QUADRAL DRIVE WADSWORTH, OHIO 44281 (330) 334-0066						
		TITLE TYPICAL RAIL SUPPORT FLASHING FLEECE DIAGRAM						
SCALE	NONE	DWN	PBF	CHK	BS	APPROVAL DATE	8/11/09	
DRAWING NUMBER	P-14						REV	0

** USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.