


ALSAN 2K FLASHING SYSTEM

LOW ODOR LIQUID MEMBRANE FLASHING SYSTEM



PRODUCT DETAILS

ALSAN 2K PRIMER

Low odor primer for improving substrate adhesion

ALSAN 2K ZERO

Dual component low odor polyurethane waterproofing resin reinforced with polyester fabric

Please refer to applicable product data sheets for additional information.

SUBSTRATE PREPARATION

Refer to substrate preparation and priming schedule. Remove existing paint and finishes etc. by mechanical means.

Ensure that the prepared surface is clean, dry and free from dust, laitance, grease, oil and any other contaminants.

Concrete substrate should have a maximum moisture content of 1.5 kg/100m²/24h (ASTM F1869) and internal content of 75 % RH (ASTM F2170).

Acceptance of the substrate is the sole decision of the owner or appointed representative.

PRIMING

ALSAN 2K PRIMER:

Apply with a lambswool roller (0.5 gal/100 ft² min.).

Alsan 2K Zero application may be applied while 2K Primer is still tacky and must be applied within four hours of application of 2K Primer.

PRODUCT PREPARATION

ALSAN 2K ZERO is a two-component system with premeasured quantities packaged in two cans. The contents of ALSAN 2K ZERO Component B should be poured into the can containing ALSAN 2K ZERO Component A.

The premeasured thickening agent (product number L-A170) is also added at this time. Using a slow-speed (200 to 400 rpm) mechanical agitator, thoroughly mix the entire container until contents are combined.

TRAFFICABLE SURFACING

Apply an even layer of ALSAN 2K ZERO (2.0 gal/100 ft² min.) with roller. Embed pre-cut ALSAN POLYFLEECE REINFORCEMENT into wet ALSAN 2K ZERO, removing all wrinkles and trapped air. Apply another even layer of ALSAN 2K ZERO (1.0 gal/100 ft² min.) wet on wet to ensure full saturation of the reinforcement.

Wait minimum of 12 hours before application of finish layer.

Apply finish coat layer of ALSAN 2K ZERO (1.0 gal/100 ft² min.).

COMPLETION

Upon completion of new installation (including all associated work), institute appropriate procedures for surveillance and protection of finished work during remainder of construction period. Protect all areas where coating has recently been installed. Notify the Owner and the Manufacturer when finished. Coordinate final inspection by Manufacturer. Complete all repairs or requests promptly. Comply with all paperwork and payment requirements necessary to acquire the specified warranty.

SOPREMA