


ALSAN RS LOW ODOR PLAZA SYSTEM

LOW ODOR LIQUID APPLIED WATERPROOFING MEMBRANE



PRODUCT DETAILS

ALSAN 2K PRIMER

Low odor primer for improving substrate adhesion

ALSAN RS 260 LO FIELD

Low odor waterproofing layer reinforced with polyester fabric

Please refer to applicable product data sheets for additional information.

SUBSTRATE PREPARATION

Refer to substrate preparation and priming schedule. Remove existing paint and finishes etc. by mechanical means.

Ensure that the prepared surface is clean, dry and free from dust, laitance, grease, oil and any other contaminants.

Concrete substrate should have a maximum moisture content of 1.5 kg/100m²/24h (ASTM F1869) and internal content of 75 % RH (ASTM F2170).

Acceptance of the substrate is the sole decision of the owner or appointed representative.

PRIMING

ALSAN 2K PRIMER:

Apply with a lambswool roller (0.5 gal/100 ft² min.)

Can be walked upon/next coat applied after approx. two hours.

FIELD AND FLASHING

Apply an even layer of ALSAN RS 260 LO (2.0 kg/m² min.) with a lambswool roller or notched squeegee.

Roll ALSAN RS FLEECE reinforcement into the wet resin, pressing trapped air free using the lambswool roller, ensuring a minimum 50mm overlap between the reinforcement sheets.

Apply ALSAN RS 260 LO (1.0 kg/m² min.) wet on wet to ensure full saturation of the fleece.

Rainproof after approx. 30 minutes.

Can be walked upon/next coat applied after approx. 45 minutes.

Able to withstand stress after approx. 2 hours.

ALSAN RS 260 LO FIELD and ALSAN RS 260 LO FLASH are applied at identical coverage rates. In Liquid applied applications, all flashing is installed first followed by the field application.

TRAFFICABLE SURFACING

Not applicable.

PLAZA SYSTEM INSTALLATION

Upon final cure of ALSAN RS 260 LO FIELD fully reinforced application, specified plaza paver / overburden system may be installed. Care should be taken during installation and any inadvertent damage to ALSAN RS membrane should be identified and repaired.

COMPLETION

Upon completion of new installation (including all associated work), institute appropriate procedures for surveillance and protection of finished work during remainder of construction period. Protect all areas where coating has recently been installed. Notify the Owner and the Manufacturer when finished. Coordinate final inspection by Manufacturer. Complete all repairs or requests promptly. Comply with all paperwork and payment requirements necessary to acquire the specified warranty.

SOPREMA