


# ALSAN RS LOW ODOR SYSTEM

## LOW ODOR WATERPROOFING MEMBRANE



### PRODUCT DETAILS

#### ALSAN 2K PRIMER

Primer for improving substrate adhesion

#### ALSAN RS 260 LO FIELD

Waterproofing layer reinforced with polyester fabric

#### ALSAN RS 263 LO SELF-LEVELING MORTAR

Heavy duty trafficking surface

#### ALSAN RS 288 FINISH

Color finish

Please refer to applicable product data sheets for additional information.

### SUBSTRATE PREPARATION

Refer to substrate preparation and priming schedule.  
Remove existing paint and finishes etc. by grinding.  
Ensure that the prepared surface is clean, dry and free from dust, laitence, grease, oil and any other contaminants.  
Acceptance of the substrate is the sole decision of the owner or appointed representative.

### PRIMING

**ALSAN 2K PRIMER:**  
Apply with a lambswool roller (0.7 gal/100 ft<sup>2</sup> min.)  
Can be walked upon/next coat applied after approx. two hours.

### FIELD AND FLASHING

Apply an even layer of ALSAN RS 260 LO (2.0 kg/m<sup>2</sup> min.) with a lambswool roller or notched squeegee.  
Roll ALSAN RS FLEECE reinforcement into the wet resin, pressing trapped air free using the lambswool roller, ensuring a minimum 50mm overlap between the reinforcement sheets.  
Apply ALSAN RS 260 LO (1.0 kg/m<sup>2</sup> min.) wet on wet to ensure full saturation of the fleece.  
Rainproof after approx. 30 minutes.  
Can be walked upon/next coat applied after approx. 45 minutes.  
Able to withstand stress after approx. 2 hours.

ALSAN RS 260 LO FIELD and ALSAN RS 260 LO FLASH are applied at identical coverage rates. In Liquid applied applications, all flashing is installed first followed by the field application.

### TRAFFICABLE SURFACING (OPTIONAL)

PLEASE BE ADVISED THAT THERE IS NO LOW ODOR VERSION OF ALSAN RS 288 FINISH. IF ODOR IS AN ISSUE, PLEASE TAKE EVERY PRECAUTION TO MINIMIZE ODOR DISSEMINATION DURING APPLICATION OF ALSAN RS 288 FINISH.

Apply ALSAN RS 263 LO SELF-LEVELING MORTAR (3.5kg/m<sup>2</sup> min.) with a notched trowel or masonry float.  
Embed into the liquid layer a full cover of crystal quartz (0.7-1.2mm) (7.0kg/m<sup>2</sup>) approx. Allow to dry for a minimum of 1 hour, sweep away excess aggregate and vacuum clean.  
Rainproof after approx 30 minutes.  
Can be walked upon/next coat applied after approx. 45 minutes.  
Able to withstand stress after approx. 2 hours.  
Apply ALSAN RS 288 COLOR FINISH (0.5kg/m<sup>2</sup> min) using a lambswool roller.  
Rainproof after approx. 30 minutes.  
Can be walked upon after approx. 2 hours.

### COMPLETION

Upon completion of new installation (including all associated work), institute appropriate procedures for surveillance and protection of finished work during remainder of construction period. Protect all areas where coating has recently been installed. Notify the Owner and the Manufacturer when finished. Coordinate final inspection by Manufacturer. Complete all repairs or requests promptly. Comply with all paperwork and payment requirements necessary to acquire the specified warranty.

SOPREMA