


INSTALL A MINIMUM 8” (20cm) WIDE BED OF SOPREMA MASTIC ONTO THE DRAIN FLANGE AND OUT ONTO THE INSULATION PRIOR TO EMBEDDING THE FIELD BASE MEMBRANE PLY INTO THE MASTIC. AFTERWARD, APPLY ANOTHER BED OF MASTIC ON TOP OF THE BASE PLY PRIOR TO THE APPLICATION OF THE PRIMED DRAIN LEAD FLASHING.

WHEN POSSIBLE INSTALL MINIMUM 4’ (10.2cm) DRAIN SUMP IN ANY ONE DIRECTION—OR THAT ADDITIONAL TAPER TO PROVIDE POSITIVE DRAINAGE.

**NOTES:**

1. DETAIL TO BE USE IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS, APPLICATION METHODS AND APPROVED DETAILS.
2. SOPREMA ADHESIVES, CEMENTS, MASTICS, PRIMERS AND SEALANTS ARE REQUIRED WHERE INDICATED.
3. WHEN A PROJECT SPECIFICATION REQUIRES SOPREMA TO WARRANT SHOP FORMED METAL(S), ROOFING CONTRACTOR MUST SUBMIT METAL SPECIFICATION AND ALL PROPOSED METAL DETAILS TO THE SOPREMA CORPORATE TECHNICAL DEPARTMENT FOR REVIEW/APPROVAL PRIOR TO BIDDING AND/OR INSTALLATION.

		310 QUADRAL DRIVE WADSWORTH, OHIO 44281 (330) 334-0066		
		TITLE <b>SOPRASTAR™ DRAIN W/ CLAMPING RING</b>		
SCALE	NONE	DWN KD	CHK	APPROVAL DATE 05.29.09
DRAWING NUMBER				REV
SPSTR-004				0

\*\* USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.