


INSTALL A MINIMUM 8" (20cm) WIDE BED OF SOPREMA MASTIC ONTO THE DRAIN FLANGE AND OUT ONTO THE INSULATION PRIOR TO EMBEDDING THE FIELD BASE MEMBRANE PLY INTO THE MASTIC. AFTERWARD, APPLY ANOTHER BED OF MASTIC ON TOP OF THE BASE PLY PRIOR TO THE APPLICATION OF THE PRIMED DRAIN LEAD FLASHING.

**NOTES:**

1. USE IN CONJUNCTION WITH SOPREMA GENERAL REQUIREMENTS AND APPROVED DETAILS WHILE CONSTRUCTING OTHER ROOF COMPONENTS TO EXCEED CURRENT EDITION REQUIREMENTS OF FM APPROVALS, SMACNA, NRCA, ANSI/SPRI ES-1 AND FLORIDA BUILDING CODE-RAS NO. 111 WITH THE MOST STRINGENT REQUIREMENTS OR RECOMMENDATIONS PREVAILING.
2. SOPREMA ADHESIVES, CEMENTS, MASTICS, PRIMERS AND SEALANTS ARE REQUIRED WHERE INDICATED.
3. WHEN LWIC IS LESS THAN 2" (5cm) BUT MORE THAN 1-1/2" (3.8cm), USE 1.2" (3cm) BASE FASTENERS 2 ROWS, STAGGERED 6" (15.2cm) O/C WITH ROWS 6" (15.2cm) APART-INCREASE REINFORCING MEMBRANE SIZE TO EXTEND BEYOND FASTENER ROWS, MIN 3" (7.6cm)

		310 QUADRAL DRIVE WADSWORTH, OHIO 44281 (330) 334-0066	
TITLE TRI-FIXX DRAIN W/ CLAMPING RING			
SCALE NONE	DWN DMT	CHK PR	APPROVAL DATE 5/1/05
DRAWING NUMBER TFDR-001			REV 0

\*\* USAGE OF THIS DRAWING IS GOVERNED BY THE TERMS OF SERVICE FOR SOPREMA DETAIL. PLEASE CONSULT THESE TERMS OF SERVICE PRIOR TO UTILIZING THIS DRAWING.